

## 600 X 800mm Ceiling Mounted Led Shower Head Installation

### Installation Note:

1. After you open the packaging, check the goods whether everything is ok if there is a defect, please contact the manufacturer or the local dealer immediately.
2. Confirm the installation size of ceiling shower shower match the installation dimensions of the pre - buried inlet pipe
3. Ceiling shower shower liner has the factory testing and debugging, do not disassemble.
4. Before install the shower, as not to block the water output, make sure to remove impurities and sludge from the pre - buried water pipe.
5. During installation time, at least two water electrical.
6. After installation, please check if the connection is tight and whether there is a leak in the pipeline.
7. Ceiling shower shower internal composition containing ABS, Silica gel and other ingredients are not resistant to high temperature Do not contact with more than 70 degrees Celsius, such as high temperature and long time
8. water pressure require: 0.2Mpa~0.5Mpa

### Part list:

No.	Commodity	Quantity
1	shower head	1
2	300mm shower hose	4
3	tee joints	2
4	expansion bolt	4
5	H4 inner hexagon spanner	1
6	lamp cup 4x20w	4

